

45 30

62 00


61 00

EASTERN NOVA SCOTIA

45 00

BALSAM FIR

ASH PERCENTAGE



593 SAMPLES



62 00

61 00



45 30

62 00

61 00

EASTERN NOVA SCOTIA

45 00


BALSAM FIR
GOLD IN ASHED TWIGS


593 SAMPLES


0 5 10 15 20 25 30 KM


62 00

61 00









45 30


62 00

61 00

EASTERN NOVA SCOTIA

45 00

BALSAM FIR COBALT IN ASHED TWIGS





593 SAMPLES





62 00


61 00

































45 30

62 00

61 00


EASTERN NOVA SCOTIA

45 00



BALSAM FIR

THORIUM IN ASHED TWIGS



593 SAMPLES



62 00

61 00

45 30


62 00

61 00

EASTERN NOVA SCOTIA

45 00

BALSAM FIR URANIUM IN ASHED TWIGS



593 SAMPLES



62 00

61 00


45 30

62 00

61 00

EASTERN NOVA SCOTIA

45 00


BALSAM FIR
TUNGSTEN IN ASHED TWIGS


593 SAMPLES


0 5 10 15 20 25 30 KM

62 00

61 00








45 30


62 00

61 00

EASTERN NOVA SCOTIA

45 00






45 30

62 00

61 00


EASTERN NOVA SCOTIA

45 00



BALSAM FIR

STRONTIUM IN ASHED TWIGS



593 SAMPLES

0 5 10 15 20 25 30 KM

62 00

61 00